



Troubleshooting Guide for Showerall

1. Is the tray / floor level where the showerwall is located?
2. Is the showerwall sealed correctly to the floor and wall in the correct location?
3. Is the wall profile plumb?
4. Top rail will not reach the back wall. Ensure that the back wall is not leaning back.
(away from the tray at the top) – The distance from the inside of the glass panel at the top to the back wall should be maximum 1000mm