

Troubleshooting

5+ Series - Pivot Door

1. Do the finished measurements on the tray comply with the adjustments listed in the product specifications book?
2. Is the tray level? (See section 2 of the site installation instructions for this particular product.)
3. Are the wall profiles stepped in? (See section 5.)
4. Are the wall profiles plumb? (Section 5.)
5. Is any part of the Enclosure overhanging the outer edge of the shower tray?
6. Are doors meeting evenly along the magnetic seal?
7. Is the gasket at the bottom of the door intact?
8. Is the unit silicone sealed correctly? (Section 15.)
9. Is there a tiling upstand fitted to the tray in front of the door opening.

Is the unit been used in conjunction with a power shower? Although the shower is power shower safe it is advisable to ensure the seals are not being subjected to the jets directly.