

IMPORTANT

Thank-you for choosing a MERLYN shower door. Please familiarise yourself with these instructions before installing.

- Do you have all the tools required?
- Is the installation site compatible with the size of door supplied?
- Are all the enclosure components present?
- Is the installation kit complete?

DO NOT attempt to install the product unless you can tick ALL 4 boxes adjacent as satisfactory.

The wall plugs supplied with the installation kit are for use in solid walls. Hollow or 'stud-partition' walls will require alternative fixings. Please consult a hardware supplier for the correct type. It may also be necessary to consult your tiling supplier about the correct method for drilling your tiles.

WARNING

HEAVY PRODUCT, ASSISTANCE MAY BE REQUIRED
USE SAFETY EYEWEAR WHEN DRILLING

Any parts missing or damaged must be reported to your supplier within 5 days of purchase.


Please state size & colour of product and part number as shown for the corresponding size of door.

INSPECT DOOR BEFORE FITTING NO CLAIMS WILL BE ACCEPTED AFTER THE DOOR HAS BEEN INSTALLED

<< MAJOR COMPONENTS >>



<< FITTING KIT >>




<< TOOLS YOU WILL NEED >>






FITTING INSTRUCTIONS - FOLLOW STEPS IN SEQUENCE



1 Ensure the shower tray is level in all directions and is properly sealed to the wall. The wall must be tiled down to the top edge of the tray. Do not angle out bottom tile.



2 Place both wall profiles V1106 at 20mm from front edge of shower tray to outside edge of wall profile, wall flange to inside, p... lumb, mark & drill holes. Fix both the wall profiles into position with screws V4111, clips V2110 and twist-on caps V2109.



3 Place one door frame A into position on top of shower tray. Position second frame and attach both together with the corner pieces V8115 and screws V4109. Use clips V2110 and twist-on caps V2109 on these screws. Long roller stops to bottom, short roller stops to the top.

4 Align frame into position, drill through frame profiles at similar position to wall fixing screws and fix to wall profiles with screws V4111, clips V2110 & twist-on caps V2109.



INSIDE TOP RAIL



5 Hang moving panels B into top frame rail, double rollers to the top.




OUTSIDE BOTTOM RAIL



INSIDE BOTTOM RAIL

6 Working from the outside. Press down on quick release rollers & insert into bottom rail. Fit chrome covers V6103 to inside of single rollers.



DOUBLE ROLLERS


SINGLE ROLLERS

NOTE POSITIONING FOR DOUBLE AND SINGLE ROLLERS



7 Fit handles V6107 to both doors.

Press down on bottom rollers to gain easy access for cleaning



INSIDE TOP RAIL

8 Fit magnetic seal V3115 to front edge of both doors.



OUTSIDE BOTTOM RAIL

9 Fit short, upright plastic seals V3104 on front of fixed panels & long seals V3105 on backs of moving panels. Ensure the bottom of the fixed panel seal V3104 sits tight to the fixed glass panel clip.




INSIDE TOP RAIL



INSIDE TOP RAIL


Ensure soft plastic parts of seals are facing each other.



LOOSEN SCREW

MOVE PANEL UP OR DOWN

10 Ensure doors are closing correctly. MAIN ADJUSTMENT is made by loosening the top roller retaining screws and moving the glass panel up or down. When correct, secure screw. Micro-adjust with hexkey as shown. Door is correctly adjusted when top & bottom wheels hit roller stops evenly.



MICRO-ADJUST WITH HEXKEY



11 Press on cover caps V2104 to wall profiles and V2101L/R to frame profiles.



SEAL INSIDE FLANGE TO WALL

OUTSIDE

12 When doors are operating correctly & magnetic seal is fully aligned proceed to sealing of unit.

24 HRS



Seal wall profile flanges to wall on inside vertically. Seal bottom rail to shower tray horizontally on outside only. Seal upright profile to wall from shower tray approx 100mm vertically on outside. Seal all vertical joints on bottom of frame on outside only. Allow unit 24hrs to set.